



FITTING INSTRUCTIONS
PART NUMBER – IMS59-60660
GS59-660

NOTE – Installation is always recommended by a competent technician.

WARNING: THESE SHOCKS ARE SUPPLIED WITH A DROOP SPACER. THIS SPACER MUST BE USED. WHERE THE OEM UPPER CONTROL ARMS ARE USED THIS SPACER MUST BE PLACED ABOVE THE STRUT TOP CAP, BELOW THE NUT. WHERE AFTERMARKET HIGH CLEARANCE UPPER CONTROL ARMS ARE USED (SUCH AS DOBINSONS UCA59-212K) THE SPACER MUST BE PLACED BELOW THE STRUT TOP CAP, TO INCREASE DROOP.

<p>Low lift options where OEM UCA's are used, mount under top nut</p>	<p>When fitted with high clearance aftermarket upper control arms such as Dobinsons UCA59-212k, mount first on strut shaft</p>
	

